



What do you want to groom?







Choose the size of your dog







(> 50 cm height)

Choose the application field









Choose the application field









Choose the application field









Select the type of coat



Image: Image of the second second

I





F

with a lot of undercoat and/or tangles

Select the type of coat



Image: Image of the second second

I





F

with a lot of undercoat and/or tangles

For the detail work of a small dog we recommend:





For the part work of a small dog we recommend:





Our flexible, cordless animal hair trimmer for the full clipping of small dogs, cats and detail work on all dog sizes





ARCO

For the full-clip of a small dog with easy coat we recommend:





ARCO

Our flexible, cordless animal hair trimmer for the full clipping of small dogs, cats and detail work on all dog sizes





For the full-clip of a small dog with thicker fur we recommend:





For the full-clip of a small dog with very thick fur we recommend:



Our most powerful and quietest animal clipper for the full clipping of large dogs and cats



MAX45

Our robust and powerful animal clipper for the full clipping of large dogs





For the detail work of a medium-sized dog we recommend:





For the part work of a medium-sized dog we recommend:





ARCO

Our flexible, cordless animal hair trimmer for the full clipping of small dogs, cats and detail work on all dog sizes





For the full-clip of a medium-sized dog with easy coat we recommend:





For the full-clip of a medium-sized dog with thicker fur we recommend:





For the full-clip of a medium-sized dog with very thick fur we recommend:





MAX45

Our robust and powerful animal clipper for the full clipping of large dogs





For the detail work of a large dog we recommend:





For the part work of a large dog we recommend:





Our flexible, cordless animal hair trimmer for the full clipping of small dogs, cats and detail work on all dog sizes





ARCO

For the full-clip of a large dog we recommend:





MAX45

Our robust and powerful animal clipper for the full clipping of large dogs





For the clip of a cat we recommend:





ARCO

Our flexible, cordless animal hair trimmer for the full clipping of small dogs, cats and detail work on all dog sizes





Product overview











REX

Our quiet animal clipper with long service life for the full clipping of medium-sized dogs

MQX50



NOSER

hm STAR BLAT 49 mm Anti-49 mm Anti-Anti-slip insert Slip-resistant

Our most powerful and quietest animal clipper for the full clipping of large dogs and cats

- Particularly powerful thanks to the power motor.
 3300 rpm. Extraordinarily light and quiet as a result.
- Precision-ground "Made in Germany" professional solid metal blade set with 1 mm cutting length and fine tooth pitch. Perfect for removing matted fur. Quick-change system for a simple replacement of the blade set and easy cleaning.

- Can be securely gripped in the hand thanks to the anti-slip insert.
- Energy-efficient plug-in transformer with low voltage - extra safety for both animal and user!
- Flexible 3 m round cable with long service life for maximum freedom of movement.

Optionally available:

Extensive MOSER STAR BLADE quick-change blade assortment adjusted for all fur types. Compatible with almost all competitive clippers with snap-on blades.







MGX50 Blade sets

	Art.no.	Cutting lenght		short, bristly, without undercoat e.g. Dalmatian, Mastiff	short, bristly, with undercoat e.g. wire-haired dachshund, West Highland Terrier	long, fine, without undercoat e.g. Maltese, Yorkshire Terrier	long, fine, with undercoat e.g. Shih Tzu, Golden Retriever, Bobtail, Pekinese	heavily swirled e.g. Poodle, Bolonka, Portuguese waterdog	matted / knotted specially breeds with long coat
010	1245-7300	1/20 mm #50F	Fine tooth blade set			\checkmark	\checkmark	\checkmark	\checkmark
010	1245-7310	1/10 mm #40F	Fine tooth blade set			\checkmark	\checkmark	\checkmark	\checkmark
0 1 0	1245-7320	1,0 mm #30F	Fine tooth blade set			\checkmark	\checkmark	\checkmark	\checkmark
0 1 0	1245-7940	2,0 mm #10F	Fine tooth blade set	\checkmark	\checkmark	\checkmark	\checkmark	\checkmark	
0 0	1221-5840	2,3 mm #10W	Coarse blade set	\checkmark	\checkmark				
	1245-7340	2,5 mm #9F	Coarse blade set	\checkmark	\checkmark	\checkmark	\checkmark	\checkmark	
010	1245-7931	3,0 mm #8,5F	Coarse blade set	\checkmark	\checkmark	\checkmark		\checkmark	
00	1245-7360	5,0 mm #7F	Coarse blade set	\checkmark	\checkmark				
0 0	1225-5870	7,0 mm #5F	Coarse blade set	\checkmark	\checkmark				
0	1225-5880	9,0 mm #4F	Coarse blade set	✓	\checkmark				

MQX45



MQX



Our robust and powerful animal clipper for the full clipping of large dogs

- Robust DC Motor with two speed settings, 2400/3000 rpm.
- Precision-ground "Made in Germany" professional solid metal blade set with 3 mm cutting length and coarse tooth pitch. Blade set quick-change system for simple replacement and easy cleaning.
- 3 m round cable with long service life for maximum freedom of movement.

Optionally available:

Extensive MOSER STAR BLADE quick-change blade assortment adjusted for all fur types. Compatible with almost all competitive clippers with snap-on blades.

> ocumenta Wege fu WOSEB







MGX45 Blade sets

	Art.no.	Cutting lenght		short, bristly, without undercoat e.g. Dalmatian, Mastiff	short, bristly, with undercoat e.g. wire-haired dachshund, West Highland Terrier	long, fine, without undercoat e.g. Maltese, Yorkshire Terrier	long, fine, with undercoat e.g. Shih Tzu, Golden Retriever, Bobtail, Pekinese	heavily swirled e.g. Poodle, Bolonka, Portuguese waterdog	matted / knotted specially breeds with long coat
010	1245-7300	1/20 mm #50F	Fine tooth blade set			\checkmark	\checkmark	\checkmark	\checkmark
	1245-7310	1/10 mm #40F	Fine tooth blade set			\checkmark	\checkmark	\checkmark	\checkmark
0 1 0	1245-7320	1,0 mm #30F	Fine tooth blade set			\checkmark	\checkmark	\checkmark	\checkmark
0 11 0	1245-7940	2,0 mm #10F	Fine tooth blade set	\checkmark	\checkmark	\checkmark	\checkmark	\checkmark	
0 0	1221-5840	2,3 mm #10W	Coarse blade set	\checkmark	\checkmark				
	1245-7340	2,5 mm #9F	Coarse blade set	\checkmark	\checkmark	\checkmark	\checkmark	\checkmark	
0 1 0	1245-7931	3,0 mm #8,5F	Coarse blade set	\checkmark	\checkmark	\checkmark		\checkmark	
0 0	1245-7360	5,0 mm #7F	Coarse blade set	\checkmark	\checkmark				
0 0	1225-5870	7,0 mm #5F	Coarse blade set	\checkmark	\checkmark				
0	1225-5880	9,0 mm #4F	Coarse blade set	\checkmark	\checkmark				

REX





Our quiet animal clipper with long service life for the full clipping of medium-sized dogs

- Quiet and robust precision drive. Long service life thanks to established technology.
- Precision-ground "Made in Germany" solid metal blade set with coarse tooth pitch.
- Integrated cutting length adjustment with 6 definable pre-set positions from 0.1 - 3 mm.
- Particularly quiet ideal for nervous, noisesensitive animals.
- Flexible 3 m round cable.











1400





Our popular animal clipper for the full clipping of small dogs with easy coats

- Robust animal clipper thanks to proven technology and the oscillating armature motor with long service life.
- Precision-ground, solid metal blade set for a long operating life.
- Integrated cutting length adjustment with 6 definable pre-set positions from 0.1 - 3 mm.
- 2 m round cable.









ARCO





Our flexible, cordless animal hair trimmer for the full clipping of small dogs, cats and detail work on all dog sizes

- Two interchangeable battery power packs for non-stop clipping. Extremely long battery operating time of up to 100 minutes and 75-minute quick charge.
- Professional high-grad steel blade set with coarse tooth pitch and quick-change system - easily removable for comfortable cleaning.
- Integrated cutting length adjustment from 0.7 3 mm directly at the blade set.
- The LED battery charge status indicator ensures that the battery can be changed on time.











Why should I groom my four-legged friend?

Poor grooming can quickly lead to matting; this causes skin problems which are very uncomfortable for the animal. Shorter fur does not merely improve your dog's well-being, but it also makes daily grooming much easier.

Start the grooming already when your dog is young in order to get him used to the clipper and the coat care. With a little bit of praise and regular grooming also adult animals get quickly used to it.

Attention when buying an animal clipper: Not every clipper is recommended for every animal.

Therefore consider the required application field and your dog's fur type when when buying an animal clipper. For soft, fluffy fur (for example: Old English Sheepdog, Poodle) a fine-toothed blade set is recommended generally. For short, bristly fur (for example: West Highland Terrier, Schnauzer) a coarse tooth blade set is recommended.

In the following you will find several grooming guides for our animal clippers.







The grooming session



If you do a full-clip you should genererally **never clip shorter than 3 mm**, as this could cause razor burn and infections. Furthermore in summer the sun burn risk is high. Work therefore with an attachment comb or a blade set with longer cutting length. Always groom with the direction of the fur growth. If you want to groom against the direction of the fur growth please note to use always a longer cutting length than you actually want to achieve. For detail work, e.g. on paws, in the face or in the genital region the fur can be a little bit shorter, but never shorter than 2 mm.

Every breed should be groomed by default. You'll receive further information to the individual coat care of your dog from your breeder or a professional dog groomer. Especially breeds with longer fur and without or only less undercoat (z.B. Maltese, Yorkshire Terrier, Poodle) should be groomed regularly. For dog breeds with undercoat the undercoat need to be removed before clipping the fur.







Overview of the grooming guides
















In order to make grooming a pleasant experience for your dog, do the grooming in a familiar environment and put him on a table however with a slip-resistant mat.

Before clipping the coat should be brushed well and large matted fur areas should be removed with an animal clipper with a fine tooth blade set or a dematter (fig. 1).

For larger areas of matted fur the MOSER Max50 with the 1 mm blade set (fig. 2), for smaller areas the MOSER Rex Mini is recommended (fig. 3). Start under the fur knot and remove carefully the matted fur. If the matted fur is close to the skin then hold the skin straight and start clipping where the fur is at its shortest.

Only if the coat is without any knots you will achieve a professional grooming result and avoid stress for your dog during the grooming session as the blade set can smoothly go through the fur.

Go to the next page



Preparation

Clipping

Care of blade sets









If you four-legged friend has played in the mud bath him before clipping because dirt and sand in the fur will decrease the blade's service life. Adjust the water temperature accordingly and use a mild animal shampoo. For shampooing a grooming glove is recommended which can be used in wet as well as in a dry environment for brushing and massaging.

Dry the fur well while brushing and keeping enough distance to the fur (fig. 4). Begin brushing by parting the hair in one place and combing downwards layer by layer.

Be careful with dogs that have fine fur!

If necessary, place a hand below the fur that is to be brushed and comb it above your hand. (fig. 5)









The preparation of the clipper



Clipping

Preparation

As soon as your dog is prepared you should also prepare the clipper for the grooming session. In ordert o make it a pleasant experience and to preserve the blade set, you should always oil the blade. Oil the blade set at the 5 most important points (fig. 6) and switch on the clipper for some seconds that the oil could be distributed properly.







The right preparation: Detach the blade set







Choose a cutting length and attach the corresponding blade set.

Attention: Always start the full-clip with a blade set with longer cutting length (starting from 7 mm) or use the attachment combs to ensure that the fur doesn't get too short. Test the chosen cutting length in advance in a small area.

How to remove easily the blade set of your Max45 or Max50:

- 1. Switch the appliance off first and pull out the plug. Then push the quick change button forwards on the rear of the clipper. (fig. 1)
- 2. Hold down the quick change button. Push the blade set slightly upwards at the front with the other hand on the carving blade. (fig. 2)
- 3. You can then remove the blade set with ease for cleaning or changing.(fig. 3)

Go to the next page



Preparation

Clipping

Care of blade sets





The right preparation: Attach the blade set



- 1. Position the blade set on the retaining plate. You will find the opening for the retaining plate on the blade set as indicated in the photo. Ensure that the retaining plate is folded out on the clipper. If this is not the case, use a flat screwdriver to fold out the retaining plate. (See operating manual in this respect). (fig. 1)
- 2. Push the blade set completely onto the retaining plate. (fig. 2)
- 3. Plug in the power supply first, then switch on the clipper again. (fig. 3)
- 4. Press the blade set onto the clipper with the motor running. This will ensure that the blade set is fitted completely and correctly to the clipper. (fig.4)



retaining plate











The right preparation: Working with attachment combs



The stainless steel attachment combs fit on the following blade set lengths: 1 mm, 2 mm, 2,5 mm, 3 mm.

TIP: The 1 mm blade set is especially recommended for working with the stainless steel attachment combs. So you can achieve cutting lengths from 3 to 25 mm!

Example:





11 mm cutting length

Blade set of 1 mm cutting length

Attachment comb of 10 mm cutting lenght

- 1. Hook the attachment comb under the blade set with the aid of the springs. (fig. 1)
- 2. Then pull the attachment comb upwards in the direction of the arrow and over the blade set ... (fig. 2)
- 3. ... and over the blade set. (fig. 3)



Preparation

Clipping

3

Care of blade sets





The back:







- 1. For the full-clip you divide the back into two parties. Start clipping in the middle of the back and then clip until the beginning of the tail. (fig. 1)
- 2. Continue then with the front part. Start at the beginning of the neck and clip completely until the beginning of the tail to get an even result. (fig. 2)
- 3. Afterwards you continue with the side parts and clip until the slight stomach. (fig. 3)



Preparation

Clipping

Care of blade sets





The legs, neck & stomach





Legs:

Then start at the shoulders and groom first the forelegs in direction to the paws (fig. 1) and then the hind legs (fig. 2). Please always hold the leg which you are shearing with one hand. Hold the skin straight in difficult areas to ensure a smooth clip. If you groom the inner legs lift the leg and then groom the innerleg of the alternate leg.

Neck & stomach:

Start clipping at the beginning of the neck and then groom towards the chest (fig. 3). Hold the dog's head slightly upwards and groom carefully downwards. For the stomach region you slightly lift the fore legs of your dog and then work in direction to the genital region (fig. 4) or if you have a large dog you could do the stomach clip directly if the dog is standing. In the genital region you could partly clip against the direction of the fur growth. Please note that the cutting length will be shorter then.

When grooming these areas please always pay attention to nipples, genitals or other sensitive areas.









The face



Dependent on the dog size you could also groom the fur in the face with the clipper (fig. 1). Always work here carefully and in direction of the fur growth.

If you want to groom smaller and difficult to reach areas a smaller animal trimmer, see below, is recommended.

For all dog breeds it is important that the paws are groomed in order to avoid infections.

For hygienic "walkies" also the fur in the stomach & genital regions should be clipped regularly. For such work a smaller and more handy animal trimmer is recommended:





The right blade set care







To achieve a long service life of the clippers and trimmers, they should be cleaned and maintained regularly.

During clipping:

In order to remove remaining fur from the blade set and to cool and oil the blade during clipping the MOSER blade ice is especially recommended.

After clipping:

- Turn off clipper and plug out the power supply.
- Remove blade from the clipper.
- Remove remaining fur with the cleaning brush (fig. 1) and oil the blade set at the 5 most important points (fig. 2).
- Put on the blade on the clipper and switch on the clipper for approx. 10 sec to ensure a proper oil distribution. (fig. 3)





Preparation

Clipping

Care of blade sets

Tips & tricks









1

WAHL

Tips & tricks for the grooming session



- If your dog isn't used to grooming it is recommended and very helpful to do the grooming together with another person. Thus you can completely concentrate on the clipping
- Get your dog slowly used to the clipper by switching on the clipper sometimes and holding it nearby him.
- If you work with difficult, thick fur and if you groom for a longer time the blade set could get warm as heat is generated by the friction from metal on metal. To avoid blade heat it is recommended to apply the MOSER Blade Ice which is sprayed on the blade and which cools and oils the blade during the grooming session.
- Hold the skin straight in hard to reach areas (e.g. popliteal space, axilla) to facilitate the grooming.

Go to the overview













In order to make grooming a pleasant experience for your dog, do the grooming in a familiar environment and put him on a table however with a slip-resistant mat.

Before clipping the coat should be brushed well and large matted fur areas should be removed with an animal clipper with a fine tooth blade set or a dematter (fig. 1).

For larger areas of matted fur the MOSER Max50 with the 1 mm blade set (fig. 2), for smaller areas the MOSER Rex Mini is recommended (fig. 3). Start under the fur knot and remove carefully the matted fur. If the matted fur is close to the skin then hold the skin straight and start clipping where the fur is at its shortest.

Only if the coat is without any knots you will achieve a professional grooming result and avoid stress for your dog during the grooming session as the blade set can smoothly go through the fur.

Go to the next page



Preparation

Clipping

Care of blade sets









If you four-legged friend has played in the mud bath him before clipping because dirt and sand in the fur will decrease the blade's service life. Adjust the water temperature accordingly and use a mild animal shampoo. For shampooing a grooming glove is recommended which can be used in wet as well as in a dry environment for brushing and massaging.

Dry the fur well while brushing and keeping enough distance to the fur (fig. 4). Begin brushing by parting the hair in one place and combing downwards layer by layer.

Be careful with dogs that have fine fur!

If necessary, place a hand below the fur that is to be brushed and comb it above your hand. (fig. 5)









The preparation of the clipper



Clipping

Preparation

As soon as your dog is prepared you should also prepare the clipper for the grooming session. In ordert o make it a pleasant experience and to preserve the blade set, you should always oil the blade. Oil the blade set at the 5 most important points (fig. 6) and switch on the clipper for some seconds that the oil could be distributed properly.







The right preparation: Working with attachment combs



Choose the attachment comb with your requested cutting length and slide it on the blade set (fig. 1 & 2). If you use attachment combs always set the blade set to the shortest cutting length.

Attention: Start the full-clip with attachment combs in order to avoid that the fur gets too short. Test the chosen cutting length in advance in a small area.





Preparation





The back







- 1. For the full-clip you divide the back into two parties. Start clipping in the middle of the back and then clip until the beginning of the tail. (fig. 1)
- 2. Continue then with the front part. Start at the beginning of the neck and clip completely until the beginning of the tail to get an even result. (fig. 2)
- 3. Afterwards you continue with the side parts and clip until the slight stomach. (fig. 3)



Preparation

Clipping

Care of blade sets

Tips & tricks





E

The legs, neck and stomach





Legs:

Start at the shoulders and groom first the forelegs in direction to the paws (fig. 1) and then the hind legs (fig. 2). Please always hold the leg which you are shearing with one hand. Hold the skin straight in difficult areas to ensure a smooth clip. If you groom the inner legs lift the leg and then groom the innerleg of the alternate leg.

Neck & stomach:

Start clipping at the beginning of the neck and then groom towards the chest. Hold the dog's head slightly upwards and groom carefully downwards (fig. 3). For the stomach region you slightly lift the fore legs of your dog and then work in direction to the genital region (fig. 4) or if you have a large dog you could do the stomach clip directly if the dog is standing. In the genital region you could partly clip against the direction of the fur growth. Please note that the cutting length will be shorter then.

When grooming these areas please always pay attention to nipples, genitals or other sensitive areas.



Go to the next page



Preparation

Clipping

Care of blade sets





The face



Dependent on the dog size you could also groom the fur in the face with the clipper. Always work here carefully and in direction of the fur growth. (fig. 1)

If you want to groom smaller and difficult to reach areas a smaller animal trimmer, see below, is recommended.

For all dog breeds it is important that the paws are groomed in order to avoid infections.

For hygienic "walkies" also the fur in the stomach & genital regions should be clipped regularly. For such work a smaller and more handy animal trimmer is recommended:







The right blade set care







To achieve a long service life of the clippers and trimmers, they should be cleaned and maintained regularly.

During clipping:

In order to remove remaining fur from the blade set and to cool and oil the blade during clipping the MOSER blade ice is especially recommended.

After clipping:

- Turn off clipper and plug out the power supply.
- Remove blade from the clipper.
- Remove remaining fur with the cleaning brush (fig. 1) and oil the blade set at the 5 most important points. (fig. 2)
- Put on the blade on the clipper and switch on the clipper for approx. 10 sec to ensure a proper oil distribution. (fig. 3)







Preparation

Clipping

Care of blade sets

Tips & tricks









1

WAHL

Tips & tricks for the grooming session



- If your dog isn't used to grooming it is recommended and very helpful to do the grooming together with another person. Thus you can completely concentrate on the clipping
- Get your dog slowly used to the clipper by switching on the clipper sometimes and holding it nearby him.
- If you work with difficult, thick fur and if you groom for a longer time the blade set could get warm as heat is generated by the friction from metal on metal. To avoid blade heat it is recommended to apply the MOSER Blade Ice which is sprayed on the blade and which cools and oils the blade during the grooming session.
- Hold the skin straight in hard to reach areas (e.g. popliteal space, axilla) to facilitate the grooming.

Go to the overview













In order to make grooming a pleasant experience for your dog, do the grooming in a familiar environment and put him on a table however with a slip-resistant mat.

Before clipping the coat should be brushed well and large matted fur areas should be removed with an animal clipper with a fine tooth blade set or a dematter (fig. 1).

For larger areas of matted fur the MOSER Max50 with the 1 mm blade set (fig. 2), for smaller areas the MOSER Rex Mini is recommended (fig. 3). Start under the fur knot and remove carefully the matted fur. If the matted fur is close to the skin then hold the skin straight and start clipping where the fur is at its shortest.

Only if the coat is without any knots you will achieve a professional grooming result and avoid stress for your dog during the grooming session as the blade set can smoothly go through the fur.

Go to the next page



Preparation

Clipping

Care of blade sets









If you four-legged friend has played in the mud bath him before clipping because dirt and sand in the fur will decrease the blade's service life. Adjust the water temperature accordingly and use a mild animal shampoo. For shampooing a grooming glove is recommended which can be used in wet as well as in a dry environment for brushing and massaging.

Dry the fur well while brushing and keeping enough distance to the fur (fig. 4). Begin brushing by parting the hair in one place and combing downwards layer by layer.

Be careful with dogs that have fine fur!

If necessary, place a hand below the fur that is to be brushed and comb it above your hand. (fig. 5)









The preparation of the clipper



Clipping

Preparation

As soon as your dog is prepared you should also prepare the clipper for the grooming session. In ordert o make it a pleasant experience and to preserve the blade set, you should always oil the blade. Oil the blade set at the 5 most important points (fig. 6) and switch on the clipper for some seconds that the oil could be distributed properly.







Detail work







Paws

Take the paw and rotate it slightly upwards. As a dog has webs you should only clip between the pads in the marked area. With a handy animal trimmer you could reach this area perfectly. In the front region towards the claws you just groom the remaining fur without going between the pads. (fig. 1)

Only for poodles:

By default the poodle paws are additionally groomed at the top of the paws. Always work here with the direction of the fur growth that it doesn't get too short. (fig. 2)

Face & ears

The ears of breeds with longer ears can be groomed as well to avoid infections and for more hygiene. (fig. 3 & 4)

Please note: Do NOT groom inside the ear cup!

Genital region

Hold your dog's tail and groom carefully and with short movements from the annus to the side (fig. 5). Males are groomed additionally around the testis. To do this, hold the hind leg slightly to reach the area better. (fig. 6)

Go to the next page



Clipping











The right blade set care







Preparation

To achieve a long service life of the clippers and trimmers, they should be cleaned and maintained regularly.

During clipping:

In order to remove remaining fur from the blade set and to cool and oil the blade during clipping the MOSER blade ice is especially recommended.

After clipping:

Clipping

- Turn off clipper and plug out the power supply.
- Remove blade from the clipper.
- Remove remaining fur with the cleaning brush (fig. 1) and oil the blade set at the 5 most important points (fig. 2).
- Put on the blade on the clipper and switch on the clipper for approx. 10 sec to ensure a proper oil distribution. (fig. 3)





Care of blade sets

Tips & tricks









WAHL

1

Tips & tricks for the grooming session



- If your dog isn't used to grooming it is recommended and very helpful to do the grooming together with another person. Thus you can completely concentrate on the clipping.
- Get your dog slowly used to the clipper by switching on the clipper sometimes and holding it nearby him.
- If you work with difficult, thick fur and if you groom for a longer time the blade set could get warm as heat is generated by the friction from metal on metal. To avoid blade heat it is recommended to apply the MOSER Blade Ice which is sprayed on the blade and which cools and oils the blade during the grooming session.
- Hold the skin straight in hard to reach areas (e.g. popliteal space, axilla) to facilitate the grooming.

Go to the overview





